

GT86-RCNV

1. REMOVE WHEEL, BRAKE CALIPER, OEM BRAKE ROTOR, ABS SENSOR BEFORE REMOVING THE OEM HUB AND HANDBRAKE ASSEMBLY.
2. INSTALL REAR CONVERSION HUB, HANDBRAKE ASSEMBLY AND ABS SENSOR. RE-USE OEM BOLTS AND TORQUE SPECS BELOW
3. RE-DRILL REAR ROTOR USING SUPPLIED GUIDE OR INSTALL ALTERNATE REPLACEMENT ROTOR WITH 5x114.3 STUD PATTERN
4. INSTALL REAR CALIPER AND WHEEL AND TORQUE TO SPECS BELOW

