

SUPU-CONV

SPACER IS USED ON THE TOP SIDE IF OEM SUBFRAME HEIGHT IS REQUIRED

BUSHING SIDE INSIDE THE SUBFRAME AND AROUND THE STEEL INSERT ARE TO BE GREASED USING LITHIUM BASE GREASE

BUSHING HOLE TO BE ORIENTED TOWARDS INSIDE WHEN INSTALLING S14 REAR SUBFRAME INTO S13

USE **EITHER** THE SUPPLIED WASHER **OR** THE OEM STAMPED BRACKET. DO NOT USE BOTH TOGETHER. THE OEM BRACKET ADDS RIGIDITY AND IT IS RECOMMENDED TO USE IT

USE **EITHER** THE SUPPLIED WASHER **OR** THE OEM STAMPED WASHER.

DO NOT USE BOTH TOGETHER

THE SPOT WELDED 5mm THICK WASHERS NEED TO BE REMOVED IF USING OEM BRACE.

