

SUPU-RISR

INSTALL THIN COLLAR BUSHING ON TOP FOR RAISED SUBFRAME OR IN THE BOTTOM FOR OEM HEIGHT

LUBRICATE THE SUBFRAME BORES AND BUSHING SIDES

USE **EITHER** THE SUPPLIED WASHER **OR** THE OEM STAMPED BRACKET. DO NOT USE BOTH TOGETHER. THE OEM BRACKET ADDS RIGIDITY AND IT IS RECOMMENDED TO USE IT

USE **EITHER** THE SUPPLIED WASHER **OR** THE OEM STAMPED WASHER.

DO NOT USE BOTH TOGETHER

THE SPOT WELDED 5mm THICK WASHERS NEED TO BE REMOVED IF USING OEM BRACE.

