

Z33X-CONV

RE-USE S CHASSIS OEM
BOLTS AND WASHERS
TORQUE TO
100 Nm (74 ft-lb)

RE-USE Z33 OEM NUTS
TORQUE TO
110 Nm (81 ft-lb)

FRONT BUSH HOLES TO
FACE TOWARDS CENTRE

REAR BUSH TO BE
OFFSET 2mm
TOWARDS CENTRE

IF USING SECOND BUSH
OFFSET TO BE 2mm
TOWARDS CENTRE

